

Connecting Your Red Link WIFI To Your Thermostat and Phone

Ensure you have an active internet connection and your Red Link Wi-Fi adapter device.

Your Red Link Wi-Fi adapter will require a 115/120 V electrical outlet within short distance of your internet router/modem.

Plug in the supplied power cord to your Wi-Fi adapter and wall outlet. Plug the ethernet cord into the Wi-Fi adapter and your modem/router.

Go to your thermostat and Press Menu > Dealer information > Your 4 Number Password is displayed as the date code > Back > Installer Setup > Enter Password > Wireless Device Manager > Add Device > Press connect button on REDlink Gateway > Wait 30-45 Second and it should say Gateway added on thermostat > No other devices to connect > Save > Done

Download the Honeywell Total Connect Comfort App from your Google Play store or Apple Store

Register for a Honeywell Account

After registration it will ask you to link the account to the thermostat by following the instructions on the screen.

If you have any trouble, please give us a call at 902 832 1067 and we can help!

